



## POST MOUNTING SYSTEMS - NTS

- 1 USE SPACERS AS REQ'D TO PLUMB UP POSTS
- 2 TYPICAL SIDE MOUNT POST INSERT PROCEDURE

<b>PROJECT DETAILS</b>		<b>FILE NO.</b> 000-0-000	
4215-A Russell Road Mukilteo, WA, 98275		Fax 425-348-8476	
Main Office 425-348-3608			
<b>GLASRAIL</b>			
DRAWN CVH	APP'D		
SCALE 1/2" = 1'-0"	DATE 5/7/2010		
<b>PM-2</b>		SHEET 2 OF 7	