


STAIR RAIL WITH HANDRAIL

STAIR RAIL WITHOUT HANDRAIL

RAILING FOR STAIRS NEXT TO EXTERIOR WALL



HANDRAIL (HR) ON EXTERIOR WALL

RAILING FOR STAIRS ALONG DECK OR WALKWAY
STAIR RAIL (WR) HAND RAIL (HR)

CONTINUOUS RETURN
HR RETURN SUPPORT

LANDING

HANDRAIL MUST EXTEND HORIZONTALLY AT LEAST 12". CHECK LOCAL CODE

HAND RAIL (HR) ON EXTERIOR WALL

FULL RETURN HANDRAIL TO POST, FASTEN SECURELY

GROUND FLOOR LANDING

IF THE STAIR JACK IS LONGER THAN 10' A CENTER POST IS REQUIRED

TYPICAL HAND RAIL AND STAIR RAIL IN MULTI-LEVEL STAIRWELL

STAIR RAIL AND HAND RAIL DETAILS - NTS

PROJECT
TECHNOTE

FILE NO.
000-0-000

4215-A Russell Road
Mukilteo, WA, 98275
Main Office 425-349-3608
Fax 425-348-8476



DRAWN
CVH

APP'D

SCALE
1/4" = 1'-0"

DATE
5/20/2010

TN-3

SHEET 3 OF 6